15.11.2018

AMPC/APPC-nn29 - Disable CPU C-state in BIOS

1. Connect a USB keyboard to the PC, make sure it works as it should
2. Power off computer
3. Power on the computer
4. When a beep is heard, press the DEL key repeatedly until the BIOS screen is shown
5. Navigate to **Advanced -> CPU Configuration -> CPU C States Support**



6. To change the value, press **Enter** and select **Disabled**, press **Enter** again.



7. To save the new setting Press **F10**, and then **Enter (Yes)**



8. The computer reboots